

# Universal Clamp & Conduit Clip




Figure 1





Figure 2

Indicated Loads are Static Load Limits  
and should not be combined

Global Part Number	Local Part Number	Figure No.	Description
812M24	N/A	1	1/2" [13] - 3/4" [19] conduit to 1/8" [3] - 1/4" [6] flange
812EM24	160120		1/2" [13] - 3/4" [19] conduit to 5/16" [8] - 1/2" [13] flange
812M58	N/A		1/2" [13] - 3/4" [19] conduit to 9/16" [14] - 3/4" [19] flange
812EM58	160130		1/2" [13] - 3/4" [19] conduit to 13/16" [21] - 1-1/8" [28] flange
812M912	N/A		1/2" [13] - 3/4" [19] conduit to 1/8" [3] - 1/4" [6] flange
812EM912	160140		1/2" [13] - 3/4" [19] conduit to 5/16" [8] - 1/2" [13] flange
812M1318	N/A		1/2" [13] - 3/4" [19] conduit to 9/16" [14] - 3/4" [19] flange
812EM1318	160075	2	1/2" [13] - 3/4" [19] conduit to 13/16" [21] - 1-1/8" [28] flange
812M24SM	160050		1/2" [13] - 3/4" [19] conduit to 1/8" [3] - 1/4" [6] flange
812M58SM	160060		1/2" [13] - 3/4" [19] conduit to 5/16" [8] - 1/2" [13] flange
812M912SM	160070		1/2" [13] - 3/4" [19] conduit to 9/16" [14] - 3/4" [19] flange
812M1318SM	160145		1/2" [13] - 3/4" [19] conduit to 13/16" [21] - 1-1/8" [28] flange




## Conduit Clip Installation



1. Select the appropriate Latching Hole from Sizing Chart
2. Fit Conduit into Conduit Clip
3. By Hand or with Channel Lock Pliers, snap Locking Tab into the desired Latching Hole

Sizing Chart	
Global Part Number	Local Part Number
812M	177130

Latching Hole "B"  
(See Sizing Chart)



Latching Hole "A"  
(See Sizing Chart)



If Assembly is mounted with Conduit in Vertical Position,  
Load must be carried by other means than this fastener

### WARNING:

1. nVent products shall be installed and used only as indicated in nVent product instruction sheets and training materials. Instruction sheets are available at [www.nVent.com](http://www.nVent.com) and from your nVent customer service representative.
2. nVent products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings.
3. All instructions must be completely followed to ensure proper and safe installation and performance.
4. Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, property damage, serious bodily injury and/or death, and void your warranty.
5. Products that are manufactured using spring steel components shall be used only in a non-corrosive indoor environment.
6. All pipe supports, hangers, intermediate components and structural attachments must ONLY be used as described herein and are NEVER to be used for any other purpose.

NOTE: All load ratings are for static conditions and do not account for dynamic loading such as wind, water or seismic loads, unless otherwise noted.

The customer is responsible for:

- a. Conformance to all governing codes.
- b. The integrity of structures to which the products are attached, including their capability of safely accepting the loads imposed, as evaluated by a qualified engineer.
- c. Using appropriate industry standard hardware as noted above.

### SAFETY INSTRUCTIONS:

All governing codes and regulations and those required by the job site must be observed.

Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.

nVent, nVent CADDY, nVent ERICO Cadweld, nVent ERICO Critec, nVent ERICO, nVent ERIFLEX, and nVent LENTON are owned by nVent or its global affiliates. All other trademarks are the property of their respective owners. nVent reserves the right to change specifications without prior notice.

### TECHNICAL SUPPORT:

[www.nVent.com](http://www.nVent.com)

CFS217.G

1 OF 1

© 1998-2020 nVent. All Rights Reserved



Downloaded by: Matthew Bennett - 2023-09-09 11:31

