





Powering Business Worldwide

DILM(C)7...M(C)15..., DILA(C), DILMP20
XTCE...B, 7-15A, XTEC...B, 7-15A
XTCF...B, 20A, XTRE..., XTRC...



DILM(C)7...M(C)15..., DILA(C), DILMP20
XTCE...B, 7-15A, XTEC...B, 7-15A
XTCF...B, 20A, XTRE..., XTRC...



DILA(C)-22 (...VDC)
+ DILA-XHI(C)(V)04
(13, 22, 31, 40)
+ DILA-XWIRN

Mounting
Montage
Montaje
Montaggio
安装
Монтаж

Dismantling
Demontage
Démontage
Smontaggio
Desmontaje
拆卸
Разборка



1 place in position
2 latch in
3 push
4 remove

1 aufsetzen
2 rasten
3 schieben
4 abziehen

1 mettre en place
2 appoggiare
3 inserire
4 extraer

1 enclicker
2 inserire a scatto
3 osaditъ
4 zafricovatъ

1 装配
2 嵌入
3 推
4 拔出



DILA(C)
DILM(C)7...M(C)15
DILMP20
XTCE...B, 7-15A
XTEC...B, 7-15A
XTCF...B, 20A
XTRE..., XTRC...


**DILM32-XHI(C)...
DILA-XHI(C)...
DILA-XHI...-S**

**XTCEXF...
XTCEXF...
XTCEXSAB...**



03/12 ILO3407013Z (AWA2100-2126, Pub51210)
Instruction Leaflet
Montageanweisung
Notice d'installation
Инструкция по монтажу
Instrucciones de montaje

mm ²	AWG	Nm	lb-in
1 x (0.75 – 6) 2 x (0.75 – 2.5)	18 – 14 20 – 16	1.2	11
–	–	–	–



mm ²	AWG
1 x (0.75 – 2.5)	18 – 14
2 x (0.75 – 2.5)	20 – 16
–	–



Z 2



DILM(C)7...M(C)15
DILMP20
7-15A XTCE,
XTEC...
XTCE015B...
XTCF020B...



Danger!
The opening of the branch-circuit protective device may be an indication that a fault has been interrupted. To reduce the risk of fire or electrical shock, current-carrying parts and other components of the controller should be examined and replaced if damaged. If burnout of the element of an overload relay occurs, the complete overload relay must be replaced.